

Bridges

10-11

9-12 this can be any switch in order to prevent the disconnect under load.

Parameters

9904 scalar freq

9905 motor Voltage

9906 motor current

9907 motor freq

9908 motor speed

9909 motor power

6601 manual

6002 DI1

6603 350

6604 350

6605 800

6606 Minimum speed, which the pump gives water and below it, there will be no water

Note this value is by rpm.

3401 0102 speed